

TRAINING DOCUMENT FOR VISUAL INSPECTION

TL IJ - AED

N.V.LUYEN

6.Mar.2015

① General information about Vision processing.

- Typical Usages of Image Sensor
- What is pixel & how to use pixel in image processing.
- Basic Configuration of PC-Based Image Processing

② Hardware training

- Kind of Camera and Lens
- How to use Camera and Lens
- Kinds of light and light system
- How to use light















**NEED JOIN
TEST AFTER
TRAINING No 1-2-3**

③ Software training

- Introduce each function in software
- How to use each function.
- How to setting threshold

④ Follow up after training





- Monthly confirm OK points & NG points => Support.

| No | JOB List | Time | 30.MAR | | | | | 31.MAR | | | | | 1.APR | | | | | 2.APR | | | | | 3.APR | | | | |
|----|---------------------------|------|---|---|---|---|---|---|--|-----|-----|-----|---|---|---|-----|-----|-------|-----|-----|---|-----|---|-----|-----|-----|-----|
| | | | 8h | 10h | 12h | 14h | 16h | 8h | 10h | 12h | 14h | 16h | 8h | 10h | 12h | 14h | 16h | 8h | 10h | 12h | 14h | 16h | 8h | 10h | 12h | 14h | 16h |
| 0 | Greatting | 0.5 |  | | | | | | | | | | | | | | | | | | | | | | | | |
| 1 | General information | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | Typical usages Camera | 1 |  | | | | | | | | | | | | | | | | | | | | | | | | |
| | What is pixel | 1.5 | |  | | | | | | | | | | | | | | | | | | | | | | | |
| | Basic configuration | 1 | | |  | | | | | | | | | | | | | | | | | | | | | | |
| 2 | Hardware information | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | Kind of Camera | 1 | | | |  | | | | | | | | | | | | | | | | | | | | | |
| | How to use Camera & Lens | 2.5 | | | | |  |  | | | | | | | | | | | | | | | | | | | |
| | Kind of Light | 1 | | | | | |  | | | | | | | | | | | | | | | | | | | |
| | How to use Light | 3.5 | | | | | | |  | | | | | | | | | | | | | | | | | | |
| 3 | Software information | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | Introduce software | 1.5 | | | | | | | | | | |  | | | | | | | | | | | | | | |
| | How to use each function | 1.5 | | | | | | | | | | | |  | | | | | | | | | | | | | |
| | How to setting threshold. | 8 | | | | | | | | | | | | |  | | | | | | | | | | | | |
| 4 | Practice | 4 | | | | | | | | | | | | | | | | | | |  | | | | | | |
| | Test | 2 | | | | | | | | | | | | | | | | | | | | |  | | | | |
| 5 | Follow up | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | Report actual theme. | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | | |


① GENERAL INFORMATION ABOUT VISUAL INSPECTION

I. TYPICAL USAGES OF IMAGE SENSOR

Image processing enables you to two-dimensionally recognize objects. Therefore, this technique is widely used for automatic inspection replaced with **visual inspection** or **check**.





II. WHAT IS A PIXEL?




- ★ 310,000 pixel camera = 640 (X direction) x 480 (Y direction)
- ★ 2,000,000 pixel camera = 1600 (X direction) x 1200 (Y direction)
- ★ 5,000,000 pixel camera = 2432 (X direction) x 2050 (Y direction)

III. USING PIXEL DATA FOR IMAGE PROCESSING



All pixels have concentration data (0 to 255 tones).


IV. STEPS OF IMAGE PROCESSING



High-performance image processor

1. Shooting: Focused image with a good contrast
2. Transfer: Rapidly transfer data to the controller without degradation.
3. Pre-processing: Process the image for optimal measurement.
Measurement: Perform processing suited for the inspection objective at a high accuracy or at a high speed.
4. Output: Communication methods to support every control device

V. IMAGE OF USE IN FIELD




② VISUAL INSPECTION HARDWARE

V • T • E •

CANON VIETNAM CO.,LTD

II. CAMERA STRUCTURE



Chú thích:

- 1 - Hệ thấu kính (ống kính máy ảnh)
- 2 - Gương phản xạ
- 3 - Cửa sập mặt phẳng lấy nét, hay còn gọi là màn sập/màn chụp (trập)
- 4 - Sensor (cảm biến)
- 5 - Màn mờ
- 6 - Lăng kính condenser
- 7 - Lăng kính 5 cạnh
- 8 - Ống ngắm

III. TYPE LENS FOR CAMERA




$$f = h \times \frac{D}{H}$$

1/4" Sensor: h=3.6 mm


1/3" Sensor: h=4.8 mm

1/2" Sensor: h=6.4 mm

f = Focal length



IV. HOW TO USE CAMERA ?



V. HOW TO SELECT PC?


| | PC 1 | PC 2 | PC 3 |
|-----------------------------|---|---|---|
| Canopus sequence | Pentium 2.6GHz DDRAM III : 4 GB Window7: 32 bit | Core i5 3.5Ghz DDRAM III: 4GB Window7: 32 bit | Core i7 3.4 GHz DDRAM III: 16GB Window7: 64 bit |
| | Win 32 bit | Win 32 bit | Win 64 bit |
| Datum | 62 | 47 | 31 |
| Trimming | 78 | 78 | 31 |
| Gen1 | 608 | 500 | 250 |
| Gen2 | 2075 | 1716 | 1154 |
| Gen3 | 608 | 499 | 265 |
| Gen4 | 218 | 188 | 109 |
| Gen5 | 296 | 250 | 125 |
| Gen6 | 62 | 47 | 32 |
| | | | |
| Total processing | 4007 | 3325 | 1997 |
| Capture, save picture..... | 3193 | 2575 | 1503 |
| Total Cycle time(ms) | 7200 | 5900 | 3500 |



VI. TYPICAL OF LIGHT

- ★ **LED**: A variety of illumination shape, size and color
Good switching characteristic
- ★ **Fluorescent light**: Expandable (wide range illumination), relatively reasonable, using a high frequency type (10 kHz or higher)
- ★ **Halogen**: High-intensity, light guiding through fiber, glow lighting
- ★ **Metal halide**: More similar to sunlight than halogen
Relatively expensive though the power consumption is small.
- ★ **Xenon**: Higher-intensity than halogen, used as strobe, relatively expensive

<Life cycle by light source>





VII. TYPICAL USAGES OF IMAGE SENSOR

- ① Determine how to apply light (specula/diffusely-reflected/transmitted light).
 - Check the characteristics of detection target (such as scratch, shape, or presence of target).
 - Based on whether the surface is plane or curved or whether it is irregular.
- ② Determine the lighting method and shape.
 - Based on the 3D and installation conditions of work piece.
 - Is the work piece ring, low angle, coaxial or dome?
- ③ Determine the lighting color (wavelength).
 - Based on the material and color of work piece and background.
 - Are they blue, red or white?

VIII. LIGHTING SYSTEM



Basics of Illumination Method

(1) Specula light - Highlights shiny parts.



Shiny parts are bright.

(2) Diffusely-reflected light - Not subject to shine.




Shiny parts are dark.

VIII. LIGHTING SYSTEM

Specular: Coaxial Incident-Light Lighting System


Installation example



The half mirror illuminates even light from the LED to the camera along the same axis as the camera axis.


Structure

Have the surface-emitted diffusion light on the half mirror and illuminate light along the same axis as the camera axis.
Effective in emphasizing changes due to irregularity or parallelism.



Detection of engraved mark on pressed parts

Recognize the engraved mark indicating the product number or specifications as pattern shape and detect a missing mark or a different model.



Simple reflected light



The mark is unclear.

Coaxial incident-light illumination




The edge of mark is emphasized.

Coaxial incident-light lighting

VIII. LIGHTING SYSTEM

Diffusely-Reflected: Low Angle (Ring) Illumination System

Installation
example



Structure

Illuminate the surface and edge of a work piece from a low angle. Irregularities on the edge and surface are difficult to recognize when directly illuminated from above because light is diffused. Illuminating such an irregularity from an angle enables you to shoot the contrast of shade.

Detection of crack of rubber seal

It is difficult to find cracks along the perimeter, surface scratches, and uneven thickness generated during shape forming even by visual inspection because they have the same color, and therefore, less contrast. This system enables you to evaluate such defects.




Simple reflected light



The crack along the perimeter cannot be recognized.

Low angle lighting



The crack on the edge is highlighted in white.


VIII. LIGHTING SYSTEM

Diffusely-reflected: Low Angle (Bar)


Structure Can evenly illuminate shiny surfaces.
Maximizes the contrast ratio of specula - reflected surface and diffusely-reflected surface by illuminating light from the angle appropriate to the detection target.

Detection of faulty coat on terminal

Detect faulty coat at the tip of terminal. Color processing distinguishes the silver color of bare metal and the gold color of coated part, which are difficult to distinguish in monochrome.




Simple reflected light



Color difference is small and lighting is not even due to shine.



Bar lighting



The difference between gold and silver colors is visible and unevenness due to shine is reduced.

Transparent sheet width inspection

Inspect the width of thin transparent glass or resin sheet.



Color difference is small and lighting is not even due to shine.



The difference between gold and silver colors is visible and unevenness due to shine is reduced.



VIII. LIGHTING SYSTEM

Transmitted: Backlight Illumination System

Structure

Illuminate the work piece from backward with surface lighting to photograph the silhouette of work piece.


The backlight illumination system enables stable inspection when measuring the width and other dimensions.



VIII. LIGHTING SYSTEM

Dome (Shadowless) Illumination System

Installation
example



Indirect light within the dome evenly illuminates a curved work piece.

Structure

Have light diffusely-reflected on the inner wall of dome to evenly illuminate the work piece from all directions.
The shadow less effect is more effective when the system is used closer to the work piece.

Normal light



Dome light



Detection of printing on the aluminum package

Evaluate the printing on the aluminum package, which is difficult to detect due to shade of irregularity and film halation, through a transparent film.



Dome light

Simple reflected light



Printing is invisible due to irregular reflection.

Dome light




The shades of background disappear and only the printing is displayed.

VIII. LIGHTING SYSTEM


Shooting Technique (Wavelength)

Relationship between the wavelength and the CCD sensitivity

Relationship between colors and wavelengths



Best sensitivity for human eyes = CCD sensitivity characteristic (around 500 nm)





Blue: 460 nm/spectral sensitivity of about 90%

Red: 660 nm/spectral sensitivity of about 60%

Blue is brighter than red by 1.5 time.

Scattering rate and transmittance



Blue with a shorter wavelength has a high scattering rate while red with a longer wavelength is difficult to scatter and has a higher transmittance.

③ SOFTWARE TRAINING

I. COLOR KNOWLEDGE

A color of pixels can separate to:

RGB value: Red, Green, Blue

HSL value: Hue, Saturation, Value



HSL value: Hue, Saturation, Luminous (lightness)

RGB = 255,0,0

RGB = 128,128,255

RGB = 0,255,0

RGB = 255,255,255



Binary:

Mô tả: Dùng để nhị phân, biến ảnh màu thành đen trắng

3 Thông số: Color (0,1,2,3), Threshold (0-255), Reverse

Nguyên tắc:


Giả sử color = 1-Red, Threshold = 110, reverse = 0

Đây là 1 ảnh có giá trị R trong RGB như sau:

| | | |
|-----|----|-----|
| 70 | 75 | 120 |
| 200 | 20 | 20 |
| 100 | 25 | 30 |

B3: Tất cả những pixel có giá trị R < 110 sẽ biến thành màu đen và ngược lại.

Nếu reverse = 1 thì ngược lại



Chương trình sẽ thực hiện với các ô 3x3 liên tiếp, các ô 3x3 có thể chòem lên nhau.

Erosion(Chỉ dùng cho ảnh đen trắng):


Mô tả: Dùng để loại bỏ nhiễu trắng.

2 Thông số: Windowareatype (0,1,2,3~3x3,5x5,9x9,15x15), Repeat times:


Nguyên tắc:

Giả sử Windowareatype = 1(3x3), Repeat times = 1

Đây là 1 ảnh đen trắng như sau:



Trong mọi ô 3x3,
nếu có tâm là điểm
đen, biến toàn bộ ô
đó thành màu đen.



Dilation(Chỉ dùng cho ảnh đen trắng):


Mô tả: Dùng để loại bỏ nhiễu đen.

2 Thông số: Windowareatype (0,1,2,3~3x3,5x5,9x9,15x15), Repeat times:


Nguyên tắc:

Giả sử Windowareatype = 1(3x3), Repeat times = 2


Đây là 1 ảnh đen trắng như sau:



Trong mọi ô 3x3, nếu có tâm là điểm trắng, biến toàn bộ ô đó thành màu trắng.



Time 1



Time 2

Median:

Mô tả: Dùng để khử nhiễu


3 Thông số: Window area type (0,1,2,3), Color (0,1,2,3), times

Nguyên tắc:

Giả sử: window area type = 1 (window = 3x3), color = 1-Red, times = 1(1 lần)

Đây là 1 hình vuông 3x3 trong ảnh có giá trị R trong RGB như sau:

| | | |
|-----|----|-----|
| 70 | 75 | 120 |
| 200 | 20 | 20 |
| 100 | 25 | 30 |



B1: Sắp xếp các giá trị R(G,B) theo giá trị tăng dần

| | | | | | | | | |
|----|----|----|----|----|----|-----|-----|-----|
| 20 | 20 | 25 | 30 | 70 | 75 | 100 | 120 | 200 |
|----|----|----|----|----|----|-----|-----|-----|



B3: Lấy giá trị giữa đó thay vào ô nằm chính giữa.

| | | |
|-----|----|-----|
| 70 | 75 | 120 |
| 200 | 70 | 20 |
| 100 | 25 | 30 |



B2: Chọn giá trị nằm ở vị trí giữa



Chương trình sẽ thực hiện với các ô 3x3 liên tiếp, các ô 3x3 có thể chòm lên nhau.

Mean(average):

Mô tả: Dùng để khử nhiễu


3 Thông số: Window area type (0,1,2,3), Color (0,1,2,3), times

Nguyên tắc:

Giả sử: window area type = 1 (window = 3x3), color = 1-Red, times = 1(1 lần)

Đây là 1 hình vuông 3x3 trong ảnh có giá trị R trong RGB như sau:

| | | |
|-----|----|-----|
| 70 | 75 | 120 |
| 200 | 20 | 20 |
| 100 | 25 | 30 |



B1: Tính trung bình giá trị độ sáng trong ô vuông



B2: Lấy giá trị đó thay vào ô nằm chính giữa.

| | | |
|-----|----|-----|
| 70 | 75 | 120 |
| 200 | 73 | 20 |
| 100 | 25 | 30 |

$$(20+20+25+30+70+75+100+120+200)/9 = 73.333 = 73$$



Chương trình sẽ thực hiện với các ô 3x3 liên tiếp, các ô 3x3 có thể chòim lên nhau.

Outline:

Mô tả: Dùng để tìm đường biên

3 Thông số: Color (0,1,2,3), Threshold, Type

Nguyên tắc:

Giả sử: color = 1-Red, threshold = 110

| | | | | |
|-----|----|-----|-----|-----|
| 70 | 75 | 120 | 120 | 120 |
| 200 | 20 | 20 | 200 | 200 |
| 100 | 25 | 30 | 210 | 210 |
| 100 | 25 | 30 | 210 | 30 |
| 100 | 25 | 30 | 30 | 30 |

Tất cả các pixel có giá trị $R \geq 110$ và ở bên cạnh nó có một pixel có giá trị $R < 110$ sẽ trở thành $R = 255$

Type = 0

| | | | | |
|-----|----|-----|-----|-----|
| 70 | 75 | 255 | 255 | 120 |
| 255 | 20 | 20 | 255 | 200 |
| 100 | 25 | 30 | 255 | 255 |
| 100 | 25 | 30 | 255 | 30 |
| 100 | 25 | 30 | 30 | 30 |

Type = 1

Tất cả các pixel có giá trị $R \leq 110$ và ở bên cạnh nó có một pixel có giá trị $R > 110$ sẽ trở thành $R = 255$


| | | | | |
|-----|-----|-----|-----|-----|
| 255 | 255 | 120 | 120 | 120 |
| 200 | 255 | 255 | 200 | 200 |
| 255 | 255 | 255 | 210 | 210 |
| 100 | 25 | 255 | 210 | 255 |
| 100 | 25 | 255 | 255 | 255 |

Extract Color:



Mô tả: Dùng để chọn lấy những giá trị màu muốn dùng

7 thông số: Low R, High R, Low G, High G, Low B, High B, logic


Nguyên tắc: Chọn các điểm ảnh có giá trị R nằm trong khoảng Low R – High R
 G nằm trong khoảng Low G – High G
 B nằm trong khoảng Low B – High B
 Logic = 0 là AND
 Logic = 1 là OR



Low R = 100
 High R = 255
 Low G = 0
 High G = 80
 Low B = 0
 High B = 255
 Logic = 0



Low R = 0
 High R = 1
 Low G = 0
 High G = 255
 Low B = 200
 High B = 255
 Logic = 0




Label:


Mô tả: Dùng để khoanh vùng một cụm màu có giá trị R hoặc G hoặc B = 255. Vùng khoanh chỉ có thể là hình chữ nhật hoặc hình vuông

* 2 thông số: Gap, Minpixel

- Gap: Khoảng cách tối đa có thể bỏ qua (ví dụ = 2)
- Min pixel: Số pixel tối thiểu của vùng. (ví dụ = 2)



- ** 3 thông số: GapX, Khoảng cách tối đa theo chiều x có thể bỏ qua (ví dụ = 3)
- GapY, Khoảng cách tối đa theo chiều y có thể bỏ qua (ví dụ = 1)
- Minpixel: Số pixel tối thiểu của vùng. (ví dụ = 2)



Particle detect:

Mô tả: Dùng để tìm những điểm bất thường so với xung quanh

3 thông số: Window area, color, threshold

Nguyên tắc:

Giả sử window area = 3 (3x3), color = 1, threshold =

Với một ô 3x3 có giá trị R như sau:

| | | |
|-----|-----|-----|
| 100 | 95 | 100 |
| 105 | 100 | 110 |
| 90 | 100 | 100 |

Giá trị trung
bình là
Average = 100

Threshold = 14



| | | |
|-----|-----|-----|
| 100 | 95 | 100 |
| 105 | 100 | 110 |
| 90 | 100 | 100 |

$R < \text{average} - \text{threshold}/2$

$R > \text{average} + \text{threshold}/2$

Threshold = 6



| | | |
|-----|-----|-----|
| 100 | 95 | 100 |
| 105 | 100 | 110 |
| 90 | 100 | 100 |

$(\text{Average} - \text{threshold}/2) < R < (\text{Average} + \text{threshold}/2)$

Chương trình sẽ thực hiện với các ô liên tiếp, các ô không thể chồm lên nhau.

Level adjust:

Mô tả: Dùng để tăng độ tương phản của ảnh

3 thông số: Color, Low threshold, high threshold

Nguyên tắc:

Giả sử Color = 1 (Red), Low threshold = 100, high threshold = 200

Tất cả những điểm có $R < 100$ và $R > 200$ sẽ trở thành màu đen.

Giá trị R của những pixel có $100 < R < 200$ sẽ được tính như sau:

$$R' = (R - 100) * 255 / (200 - 100).$$

JUDGEMENT FUNCTION

1. Counting Pixel


4. Measurement height.

2. Counting Label

5. Measurement wide.

3. Pattern matching

Example:



OK




Failed


Failed

Tolerance: Set to 800 pixels

③ VISUAL INSPECTION SOFTWARE 6-Mar-2015 PROGRAM INTERFACE



SOFTWARE DEBUGGING




**Step1:
Extra color**

**Step2:
Binary**

**Step3:
Make label**

**Step4: Count
pixels**



PRM AND SPEC FILE SETTING

```
[GEN1]
titlle = "check black dot"

step1 = "level adj+ extract color"
ena1 = 1
prm10 = 150           ;adjlvlow
prm11 = 230           ;adjlvHi
prm12 = 255           ;Red Hi - extract

step2 = "outline"
ena2 = 1
prm20 = 5             ;outline times (=1,2,3,4,5)
prm21 = 1             ;nth out ine

step3 = "Extract"
ena3 = 1
prm30 = 0             ;R low
prm31 = 254           ;R Hi
prm32 = 0             ;G Lo
prm33 = 255           ;G Hi
prm34 = 0             ;B Lo
prm35 = 255           ;B Hi

step4 = "particle"
ena4 = 1
prm40 = 20            ;nwndAreaSize
prm41 = 20            ;nth
prm42 = 1             ;n color

step5 = "label"
ena5 = 1
prm50 = 5;4           ;nBoundDist
prm51 = 40;30 ;min pixel = 30 ;nMinDots

step6 = "count"
ena6 = 1

step7 = "cout"
ena7 = 1]
```

Default spec

```
[GEN1: center]
area_pix = 2095, 1139, 2919, 2602
ena1 = 0
ena2 = 0
prm41 = 30
prm51 = 20;10
spec = 0,0
;
;
;nth parical
;nMinDots label
```

Individual
spec

MEANING OF PRM FILE

Open program to see...

MEANING OF SPC FILE

Open program to see...


MEANING OF SCRIPT FILE

Open program to see...


Testing with actual samples

Using Mold program to detect:


1. Short mold
2. Black dot (abnormal point on the surface of part)



OK SAMPLE



NG SAMPLE



THANKS YOU FOR YOUR LISTENSNING

